

Quick Start Guide

IBIZA

150W LED Bee eye | Aperture + Six Arms、



MACROLITE

www.macrolite.store

1. IMPORTANT SAFETY



Caution

To reduce the risk of fire or electric shock, do not expose this appliance to rain and moisture. The apparatus shall not be exposed to dripping or splashing liquids and no objects filled with liquids, such as vases, shall be placed on the apparatus.



Caution

These service instructions are for use by qualified service personnel only. To reduce the risk of electric shock do not perform any servicing other than that contained in the operation instructions. Repairs have to be performed by qualified service personnel.

1. Open-package Inspection

When you receive the product, please check whether the product is damaged during transportation, and verify that the master case includes the following parts:

Moving Head light: 1 pc
Signal cable: 1 pc
User's manual: 1 pc

For reasons of safety and approval (CE), any personal reconstruction and/or modification of this product is prohibited. Please note that damage caused by modifications performed manually to this device is not covered by the warranty.

This product leaves our factory in perfect condition. Please follow all notes in these operating instructions to maintain this condition and ensure the safe operation of the product.

Any damage caused as a result of non-compliance with these operating instructions voids the warranty. The manufacturer does not accept liability for

damage to property or personal injury resulting from improper handling or failure to observe these instructions.

Store these operating instructions in a safe place for later reference, and pass them to any new holder when selling, lending, or transferring this device to another party.

2. Instruction


This product is a lighting effect that creates special light effects with one lamp. To generate these effects, the product must be connected to mains and a DMX-512 compatible controller.

This product is designed for 110–220V, 50/60Hz A/C operation and exclusively for indoor use.

If used for any purpose other than those described in these operating instructions, the device may suffer damage and the warranty becomes void. Any other use involves risks such as short circuits, electric shock, etc.

3. Safety and Maintenance:

- Indoor use only
- Make sure the equipment load-bearing structures can withstand more than 10 times the weight of the fixture when installed above ground.
- Disconnect from power supply before replacing lamp, fuse, or other accessories.
- Operate only under electrical standards with leakage protection device A/C.
- Allow the unit to cool down for 15 minutes before replacing lamps.
- Do not use accessories or parts from other companies.
- Contact your specialized dealer for any technical problems.



Please read this manual carefully before operating this product.

4. DISPLAY MENU

LCD Menu Instruction

d001	d001 –d512	512
SLoU	d512	DMX work pattern
	Red	Red light
	GrEE	Green light
	BluE	Blue light
	Wht1	White light
	LESr	Red laser
	LESG	Green laser
	Wht2	White light + golden light strobe
	A1	Walk-in mode 1 (laser + beam + strobe)
	A2	Walk mode 2 (laser + beam, no stroboscopic)
	A3	Walk-in mode 3 (beam-only, no laser)
	S1	Walk-in mode 3 (beam-only, no laser)
	S2	Walk-in mode 3 (beam-only, no laser)
SEns	0-100	Modify the voice control sensitivity with the UP or DOWN key S
SPEd	1-9	running speed
LEd	ON	The display screen is always bright and extinguished
	OFF	Turn off the LED display after 10 seconds
disp	OFF	Show positive
	ON	Show reverse
irC	ON	Turn on the remote control function
	OFF	Close the remote control function
rst	Yes/no	manual reset

5. DMX CHANNELS

15 Channels

CH	VALUE	FUNCTION
1	0-255	X axle
2	0-255	X axis speed
3	0-255	The bee eye rotation
4	0-255	Light beam motor 1
5	0-255	Light beam motor 2
6	0-255	Light beam motor 3
7	0-255	Beam motor 4
8	0-255	Light beam motor 5
9	0-255	Light beam motor 6
10	0-255	Total dimming
11	10-255	strobeflash
12	0-255	Bee eye red
13	0-255	Bee eye green
14	0-255	Bee eye blue
15	0-255	Bee eye white
16	0-255	Light beam red
17	0-255	Light beam green
18	0-255	Light beam blue
19	0-255	Light beam white
20	0-255	Red laser
21	0-255	Green laser
22	0-255	White light flash
23	0-255	Golden light flash
24	0-127	OFF
	128-255	ON
	0-255	Lamp strip effect
	0-255	Lamp strip speed
	000-012	NF
	013-021	The light with red
	022-030	The light with green
	031-039	The light is blue
	040-048	The light with yellow
	049-057	Light with purple
	058-066	The light is cyan
	067-075	The light with white
076-255	31 kinds of lamp with running water effect	

6. IMPORTANT

SETUP

Disconnect the power cord before replacing a fuse and always replace with the same type fuse .

Fuse replacement

With a flat head screwdriver wedge the fuse holder out of its housing .

Remove the damaged fuse from its holder and replace with exactly the same type of fuse .

Insert the fuse holder back in its place and reconnect power .

The fuse is located inside this compartment , remove using a flat head screwdriver .

Fixture Linking

You'll need a serial data link to run light shows of one or more fixtures using a DMX512 controller or to run synchronized shows on two or more fixtures set to a master/slave operating mode .

The combined number of channels required by all fixtures on a serial data link determines the number of fixtures that the data link can support .

Important: Fixtures on a serial/data link must be daisy chained in one single line .

Maximum recommended serial data link distance: 100 meters (1640 ft.)

Maximum recommended number of fixtures on a serial data link: 32 fixtures .

Data Cabling


To link fixtures together you must use data cables .

If you choose to create your own cable , please use data grade cables that can carry a high-quality signal and are less prone to electromagnetic interference .

Cable Connectors

Cabling must have a maleXLR connector on one end and a female XLR connector on the other end .

DMX connector configuration



Termination reduces signal errors . To avoid signal transmission problems and interference , it is always advisable to connect a DMX signal terminator .

Caution

Don't allow contact between the common and the fixture's chassis ground . Grounding the common can cause a ground loop , and your fixture may perform erratically .

Test cables with an ohm meter to check correct polarity and to make sure the pins are not grounded or shorted to the shield or each other .

Setting up a DMX Serial Data Link

1. Connect the (male) 3-pin connector side of the DMX cable to the output (female) 3-pin connector of the controller .

6. IMPORTANT

2. Connect the end of the cable coming from the controller , which will have a (female) 3-pin connector , to the input connector of the next fixture consisting of a (male) 3-pin connector .
3. Then , proceed to connect from the output as stated above to the input of the following fixture , etc.

returned , it is important that the fixture be returned in the original factory box and packing.

Sound Activated Mode

The unit responds to sounds picked up by the built-in microphone to create a light show .

The sound changes the color and the position of the effect .

This mode enables the unit to act as a Master to other Slave units .

Built-in Program Mode

As the unit can be mounted hung on a truss system or stand on a flat surface , pan, tilt and LED display settings can be reversed to provide correct coverage and ease of use .

Unpacking Instructions

Immediately upon receiving a fixture , carefully unpack the carton and check the contents to ensure that all parts are present and have been received in good condition .

Notify the freight company immediately and retain packing material for inspection if any parts appear to be damaged from shipping or the carton itself shows signs of mishandling .

Keep the carton and all packing materials .

In the event that a fixture must be



experience the light.

MACROLITE

www.macrolite.store

© MACROLITE is a registered trademark of La Polla S.A.
Document Number 001 | Vs1 | 30. Oct 2025
Specifications subject to change without prior notice.